SAFETY

Pre-collision System

The pre-collision system retracts the front seatbelts and brings the brake control system to the brake assist standby condition under the below conditions before a collision to reduce injury to the driver and front passenger.

Operating Condition	● When a collision with an obstacle in front of the vehicle or the vehicle ahead is determined to be unavoidable. ● When the front wheels lose grip in relation to the rear wheels (front wheel skid tendency). ● When the rear wheels lose grip in relation to the front wheels (rear wheel skid tendency). ● When the brakes are suddenly applied.



01YMO45Y